



Tablet Granulation

Lecture 3


Industrial pharmacy

5th class

Ist semester

Basic Characteristics

The characteristic of a tablet that make it a popular dosage form:



Properties required by compression machine design:

Materials intended for compaction into a tablet must posses two characteristics: Fluidity and Compressibility.

I. Fluidity:

A good flow properties are essential for the transport of the material through the hopper, into and through the feed frame, and into the dies.

(i.e: Tablet materials should be in a physical form that flow smoothly and uniformly).



The ideal physical form for this purpose is spheres (these offer minimum contact surfaces between themselves and with the walls of machine parts).



Note: Unfortunately, most materials do not easily form spheres; however, shapes that approach spheres improve flowability.

The purpose of granulation:

Attempts to improve the flow of powdered materials by forming sphere like or regularly shaped aggregates called granules.



2. Compressibility

Is the property of forming a stable, compact mass when pressure is applied.

In terms of compressibility, it is possible to state that granulation is the pharmaceutical process that **converts a mixture of powders which have poor cohesion, into aggregates capable of compaction.**



Granulation properties

There are many formulation and process variables involved in the granulation step can affect the characteristics of the granules produced.

The methods used to measure granulation characteristics to monitor granulation suitability for tabletting:

1. Particle size and shape.

P.S. of a granulation is known to affect:

- a. Average tablet weight
- b. Tablet weight variation
- c. Disintegration time
- d. Granule friability
- e. Granulation flowability
- f. Drying rate kinetics of wet granulations.



The granule size and size distribution, bulk granulation characteristics and final tablet characteristics depend upon:

1. **Formulation ingredients and their concentrations**
2. **Type of granulation equipment**
3. **Processing conditions**

Methods used for measuring and interpreting P.S. and P.S. distribution:

Microscopy, Sieving, Sedimentation,
Adsorption, Electrical-conductivity, Light
scatring X-ray.

2. Surface area (S.A.)

The determination of S.A. of finely milled drug powders may be of value for drugs that have only limited water solubility.



In these cases, particle size (P.S.), and especially the surface area of the drug, can have a significant effect upon dissolution rate.




An inverse relationship normally exists between P.S. and S.A.; however, granulations can have convoluted structures with considerable internal surface.


The two most common methods for determining S.A. of solid particles are:

Gas adsorption and Air permeability

The amount of gas that is adsorbed onto the powder to form monolayer.



The rate at which air permeates a bed of powder is used to calculate the S.A. of the powder sample.



3. Density.

Granule density may influence:

- a. Compressibility
- b. Tablet porosity
- c. Dissolution.



Note: Dense, hard granules may require higher compressible loads to produce a cohesive compact.



Increasing the tablet disintegration and drug dissolution times.



Even if the tablets disintegrate readily, the harder, denser granules may dissolve less readily.



At the same time, harder, denser granules are usually less friable.

Two methods are used to determine granule density. Both involve the use of a pycnometer. In one, the intrusion fluid is mercury, and in the other, it is a solvent of low surface tension (e.g., benzene) in which the granules are not soluble.

Notes: **1-** The accuracy of these pycnometer methods depends on: (the ability of the intrusion fluids to penetrate the pores of the granules).

2- Bulk density largely depends on particle shape. (As the particles became more spherical in shape, bulk density is increased).

3- As the granule size increases, bulk density decreases.



(The smaller granules are able to form a close, more intimate packing than larger granules).

4. Strength and friability.

A granule: is an aggregation of component particles that are held together by bonds of finite strength.

- The strength of a wet granule is due mainly to surface tension of liquid and capillary forces.

Surface tension

➤ The **cohesive** forces among the liquid molecules are responsible for this phenomenon

Water molecule at surface

Water molecule below surface

Water molecule

Hydrogen bond

Capillary Action

- The combined force of attraction among water molecules and with the molecules of surrounding materials is called **capillary action**.
- Capillary action allows water to move through materials with pores or narrow spaces inside.

Granule strength depends on:

1. Base materials
2. Kind and amount of granulating agent used
3. Granulating equipment used

Granule strength and friability affect:

- i. Changes in particle size distribution of granulations
- ii. Compressibility into cohesive tablets.

Methods used to measure granule strength:

- a) Granule is placed between anvils and the force required to break the granule is measured
- b) Friability measurement.

5. Flow properties.

The flow properties of a material result from many forces. Solid particles attract one another, and forces acting between particles when they are in contact are predominately surface forces.

There are many types of forces that can act between solid particles:

1. Frictional forces
2. Surface tension forces
3. Mechanical forces caused by interlocking of irregular shape
4. Electrostatic forces
5. Cohesive or van der Waals forces.






Figure 3: Electrostatic forces



- **All of these forces can affect:**

1. **Flow properties of a solid.**

2. **Granule properties:**

- a) **Particle size**
- b) **Particle size distribution**
- c) **Particle shape**
- d) **Surface texture or roughness**
- e) **Residual surface energy**
- f) **Surface area.**



Ex: With fine powder ($\leq 150\mu\text{m}$), the magnitude of the frictional and van der Waals forces usually predominate.

For larger particles ($> 150\mu\text{m}$) such as granules produced by a wet granulation technique, frictional forces normally predominate over van der Waals forces.

The two most common methods that can be employed as flow measurements are:

- A. Repose angle**
- B. Hopper flow rate measurements.**

- Values for angles of repose $\leq 30^\circ$ usually indicate a free-flowing material
- angles $\geq 40^\circ$ suggest a poorly flowing material.



6. **Compaction.**

The basic tool for studying the compression process (compacting powder or granule materials) is the instrumented tablet press.

- Tablet presses are instrumented by **affixing transducers** (to measure the forces applied during the compression process).



The signals produced by the transducer system are monitored by computer.

